



EXTERIOR PERIMETER TREATMENT

It is required that all structures, regardless of the type of construction, be protected by establishing a vertical treated zone along the outer perimeter of the foundation wall. Consult the OUTER FOUNDATION WALLS section of this label (see below) for detailed directions on this treatment procedure.

1. **OUTER FOUNDATION WALLS:** Application must be made by trenching, or where appropriate (see below) by trenching, or trenching and rodding from the bottom of the trench, around the outside of the foundation walls. When trenching, excavate a trench along the outside foundation that is about 6 inches wide and 6 inches deep. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth to provide a uniform vertical treated zone.

- For shallow foundations, one foot or less of depth, dig a narrow trench that does not exceed 6 inches wide and 6 inches deep along the outside of the foundation walls, being careful not to dig below the bottom of the footings. For foundations with exposed footings, dig a trench alongside the footing taking care not to undermine the footing.
- For basements and other foundations deeper than one foot, the application must be made by trenching and rodding from the bottom of a shallow trench. When rodding, rod holes must be spaced in a manner that will allow for a continuous treated zone, not exceed 12 inches, to be deposited along the treated area. Rod holes must not extend below the footing. Rodding depth must be to the top of the footer, or to a minimum depth of 4 feet, or according to state or local regulations.
- For all applications, apply the solution into the trench and mix with the excavated soil as it is replaced into the trench. Use a low-pressure spray to treat soil that will be replaced into the trench after rodding. Mix spray solution with the soil as it is being replaced in the trench.

Where direct access to soil on the outer foundation wall is impossible due to attached porches, entrance platforms, garages and similar slab structures, consult the CONCRETE SLAB-ON-GROUND section of this label for directions on treatment of soil beneath these structures. However, where obstructions (e.g., concrete walkways) adjacent but not attached to foundation, or where soil type and/or conditions, prevent trenching the exterior perimeter treatment may be performed at the obstructed location by rodding alone. When rodding, rod holes must be spaced in a manner that will allow for a continuous treated zone, not exceed 12 inches, to be deposited along the treated area.

2. **CONCRETE SLAB-ON-GROUND:** To treat soil beneath a slab, including attached porches, carports, entrance platforms, garages and similar slab structures abutting the foundation wall, it is necessary to drill through the slab. If an infestation is associated with an expansion joint, crack, utility penetration, or similar access point in the slab, treat by drilling and injecting through the slab. Drill holes must be spaced in a manner that will allow for application of a continuous chemical treated zone, but must extend a minimum of 3 feet on both sides of the infested site. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet.

DO NOT MAKE TREATMENT UNTIL LOCATION OF HEAT OR AIR CONDITIONING DUCTS AND VENTS ARE KNOWN AND IDENTIFIED. USE EXTREME CAUTION TO NOT CONTAMINATE DUCTS AND VENTS. Plug and fill all drilled holes in commonly occupied areas with suitable sealant. Plugs must be of non-cellulose material or covered by an impervious, non-cellulose material.

3. **INACCESSIBLE CRAWL SPACES:** If termite activity is found along the perimeter wall or on a pier within an inaccessible crawl space, areas with termite activity must be treated. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet to create a vertical treated zone, which must extend a minimum of 3 feet on both sides of the infested site.

Optional directions for horizontal rodding: Treatment may also be made by drilling through the foundation wall (or through the floor above) to treat the soil along the perimeter wall at a rate of 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet. Drill spacing must be at intervals not to exceed 16 inches. Many states have shorter intervals so check state regulations which may apply.

If termite activity is neither along the perimeter wall nor on a pier within the inaccessible crawl space, to prevent subterranean termites from constructing mud tubes between soil in the crawl space and wooden elements in the structure, an overall soil treatment of this product may be applied. Remove all cellulose debris before application. Apply 1 gallon of solution (see APPLICATION VOLUME) per 10 square feet to provide a uniform chemical treated zone.

4. **ACCESSIBLE CRAWL SPACES:** If termite activity is found within an accessible crawl space, the area(s) where termite activity exist must be treated by trenching, or trenching and rodding from the bottom of the trench, along the interior foundation walls, around piers, interior supports in contact with the soil, plumbing, or utility services. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet, per foot of depth, to create a vertical treated zone, which must extend a minimum of 3 feet on both sides of the infested site. Rodding may be done from the bottom of a shallow trench to the top of the footing or to a minimum of depth of 4 feet. When rodding, rod holes must be spaced in a manner that will allow for a continuous treated zone, not to exceed 12 inches, to be deposited along the treated area. Rod holes must not extend below the footing. When trenching, dig a narrow trench about 6 inches wide and 6 inches deep. Use a low-pressure spray to treat soil which will be placed in the trench, mixing the spray solution with soil as it is being placed in the trench.

RESTRICTION:

Do not allow people or pets to contact or to reoccupy the contaminated areas of the structure until the clean up is completed.

INTERIOR SPOT TREATMENT

For all applications, treatment must be made to all known infested sites inside the structure. One or more of the following application methods must be used to make interior spot treatments:

- Sub-slab injections made through the slab at or near areas where termites are known to be penetrating the slab to reach wood in the structure and/or at or near sites of active infestations. Apply 4-gallons per 10 linear feet per foot of depth. Sub-slab injections must extend to a minimum of 3 feet on both sides of every known infested site at expansion joints or cracks in slabs.
- Void treatments using injection of sprays, mists or foams into above ground structural voids, termite carton nests, and other infested locations.
- Wood treatments using injection techniques and/or surface applications, to treat active infestations in structural timbers.

To maximize dispersion of treatment solution in soil and in above ground locations, the use of foam and directional dispersion tips is encouraged for all interior spot treatments. Consult section(s) of this label appropriate to the element of construction, FOAM APPLICATIONS or CONTROL OF WOOD INFESTING PESTS for detailed directions on any of these treatment procedures.

1. **INTERIOR SLABS:** When termite activity is located within an interior wall or structural member, the soil beneath the slab and the wall void at this site of activity must be treated. The source of infestation at an expansion joint, crack, through a utility penetration, or similar access point in the slab, must be treated by cutting and injecting through the slab. Drill holes in the slab must be spaced in a manner that will allow for application of a continuous chemical treated zone, which must extend a minimum of 3 feet on either side of the infested site. Apply 4 gallons of solution (see APPLICATION VOLUME) per 10 linear feet. To maximize dispersion of treatment solution in soil, the use of foam and directional dispersion tips is encouraged. To treat the wall void, consult section(s) of this label appropriate to the element of construction, FOAM APPLICATIONS or CONTROL OF WOOD INFESTING PESTS for detailed directions on any of these treatment procedures.

DO NOT MAKE TREATMENT UNTIL LOCATION OF HEAT OR AIR CONDITIONING DUCTS AND VENTS ARE KNOWN AND IDENTIFIED. USE EXTREME CAUTION TO NOT CONTAMINATE DUCTS AND VENTS. Plug and fill all drilled holes in commonly occupied areas with suitable sealant. Plugs must be of non-cellulose material or covered by an impervious, non-cellulose material.

2. **HOLLOW BLOCK FOUNDATION OR MASONRY VOIDS:** Termite activity located within hollow-block foundations or masonry voids must be treated. Spot treatment at the site(s) of termite activity must extend a minimum of 3 feet on both sides. Treat masonry voids by applying 2 gallons of solution per 10 linear feet to the lower part of the void so that it reaches the top of the footing or soil. Drill spacing in masonry voids must be at intervals not to exceed 16 inches; states may have shorter intervals so check state regulations which may apply. To maximize dispersion of treatment solution in voids, the use of foam and directional dispersion tips is encouraged. To treat structural voids above sites of termite activity in masonry, consult section(s) of this label appropriate to the element of construction, FOAM APPLICATIONS or CONTROL OF WOOD INFESTING PESTS for detailed directions on any of these treatment procedures.

Treatment of voids in block or rubble foundation walls must be closely examined. Applicators must inspect areas of possible runoff as a precaution against application leakage in the treated areas. Some areas may not be treatable or may require mechanical alteration prior to treatment. All leaks resulting in the deposition of termiteicide in locations other than those prescribed on this label must be cleaned up prior to leaving the application site (refer to Precautionary Statements).

RESTRICTION:

Do not allow people or pets to contact or to reoccupy the contaminated areas of the structure until the clean up is completed.

3. **BATH TRAPS:** If termite activity is observed within 2 feet of the bath trap, then exposed soil or soil covered with tar or a similar type of sealant around plumbing and/or drain pipe entry areas must be treated. Tar or sealant may have to be removed to allow for adequate soil treatment. An access door or inspection portal should be installed if one is not present. After inspection and removal of any wood or cellulose debris, the soil can be treated by rodding or drenching the soil at a volume of no less than 3 gallons of solution per square foot.

4. **SHOWER OR FLOOR DRAINS:** If termite activity is observed within 2 feet of a shower or floor drain in the slab, then soil beneath the drain must be treated. Drill through the slab adjacent to the drain and use sub-slab injection to apply solution to the soil. Multiple access points may be drilled adjacent to the drain. Treat soil at a volume of 1 gallon of solution per square foot.

FOAM APPLICATIONS

Construction practices, soil subsidence and other factors may create situations in which a continuous chemical treated zone cannot be achieved using conventional treatment alone. In situations where necessary, conventional application methods can be supplemented through use of foam generating equipment, or similar devices, to provide a continuous treated zone.

Foam application may be made alone or in combination with conventional application methods, provided that the labeled amount of active ingredient per unit area is used.

**Foam Application Use Directions:** Mix solution of Premise 75 Insecticide In Water Soluble Packets with manufacturer's specified volume of foaming agent (see table for foaming instructions). Apply a sufficient volume of Premise 75 Insecticide In Water Soluble Packets foam alone or in combination with liquid solution to provide a continuous treated zone at the specified rate for specific application sites. Use appropriate dispersion tips and application method for site.

MIXING TABLE FOR Premise 75 Insecticide In Water Soluble Packets FOAM				
Premise 75 PACKETS <sup>a</sup>	GALLONS OF WATER	FOAM EXPANSION RATIO	FINISHED FOAM	
			(gallons)	(a1%)
One	1	25:1	25	0.05
	2.5	10:1		
	5	5:1		
Two	1	50:1	50	
	2.5	20:1		
	5	10:1		

<sup>a</sup> Add the manufacturer's specified quantity of foam agent to the Premise 75 Insecticide In Water Soluble Packets solution.

Depending on the circumstances, foam applications may be used alone or in combination with liquid solution applications. Applications may be made behind veneers, piers, chimney bases, into rubble foundations, into block voids or structural voids, wall voids, under slabs, stoops, porches, or to the soil in crawlspaces, and other similar voids.

**Foam and liquid applications must be made in accordance with volume and active ingredient instructions in order to ensure proper application has been made. The volume and amount of active ingredient are essential to an effective treatment. At least 75% of the gallons of Premise 75 Insecticide In Water Soluble Packets must be applied as a typical liquid treatment. The remaining 25% or less gallons are delivered to appropriate locations using a foam application.**

When foam is used solely to kill subterranean termites in above ground locations (such as feeding galleries in wooden framing), or in voids with framed walls, and whenever the target pest is other than subterranean termites (drywood termites, beetles, ants, etc.), dilute solutions of Premise 75 Insecticide In Water Soluble Packets may be expanded by foaming without concentrating the Premise 75 Insecticide In Water Soluble Packets solution as previously described for spot applications. Add the manufacturers' specified volume of foaming agent to produce foam of the desired expansion ratio. Use application tips and methods suitable to the site and pest.

CONTROL OF WOOD INFESTING PESTS

For control of above ground termites and carpenter ants in localized areas, apply a 0.05 to 0.1% solution or sufficient volume of Premise 75 insecticide In Water Soluble Packets foam to voids and galleries in damaged wood, and in spaces between wooden structural members and between the sill plate and foundation where wood is vulnerable. Applications may be made to inaccessible areas by drilling, and then injecting the suspension or foam with a suitable directional injector into the damaged wood or wall voids. Termite carton nests in building voids can be injected with a 0.05 to 0.1% suspension or foam. Multiple injection points to varying depths may be necessary. It is desirable to physically remove carton nest material from building voids when such nests are found. Application to attics, craw spaces, unfinished basements, or man-made voids may be made with a coarse fan spray of 0.05 to 0.1% solution or foam to control exposed worker and winged reproductive forms of termites or carpenter ants. This type of

application is intended to be a supplemental treatment for control of above ground subterranean termites and carpenter ants.

It is recommended to remove or prune away any shrubbery, bushes, and tree branches touching the structure. Vegetation touching the structure may offer a route of entry for ants into the structure. This may allow ants to inhabit the structure without coming in contact with the treatment. If nests are found, direct treatment of Premise 75 Insecticide In Water Soluble Packets can be made to these nests.

Use a 0.05 to 0.1% solution to control existing infestations of or to prevent infestation by termites or carpenter ants in trees, utility poles, fencing and decking materials, landscape timbers and similar non-structural wood-to-soil contacts. If possible, locate the interior infested cavity and inject a 0.05 to 0.1% solution or sufficient volume of Premise 75 Insecticide In Water Soluble Packets foam using an appropriate treatment tool with a splashback guard. These non-structural wood-to-soil contacts may also be treated by applying a solution to the soil as a spot application or continuous treated zone applied as a drench or by rodding around the base of the point(s) of soil contact(s). Rod holes should be placed approximately 3 inches away from the soil contact point(s) and spaced no more than 12 inches along the perimeter of the soil contact(s). For small poles or posts (< 6 inches in diameter), apply 1 gallon per foot of depth. For larger constructions, apply 4 gallons per 10 linear feet per foot of depth. Retreat as needed to maintain protection. Termite carton nests in trees may be injected with a 0.05 to 0.1% solution or sufficient volume of foam using a pointed injection tool. Multiple injection points to varying depths may be necessary. Removal of carton material from trees is desirable but may not be necessary when foam application is used. In some instances, a perimeter application of a 0.05 to 0.1% solution applied to soil around the root flare of the tree may be necessary to prevent reinfestation by termites in the soil. For small trees (< 6 inches in diameter), apply 1 gallon of solution. For larger trees, apply 4 gallons per 10 linear feet (measured as the circumference at the root flare).

For protection of firewood or other wood products stored in contact with soil from carpenter ants and termites, treat soil prior to stacking with a 0.05 to 0.1% solution at 1 gallon per 10 square feet to prevent infestation. Curative application to the soil around firewood or other wood products stored in contact with soil may be made as needed for non-structural wood-to-soil contacts (above).

**Drywood termites and wood-infesting beetles or borers** (such as, but not limited to, powder post beetles, anobiid or deathwatch beetles, false powder post beetles, old house borers, wharf borers, or ambrosia or bark beetles). Galleries and structure voids can be treated with sprays, mists, or foams of a 0.05 to 0.1% Premise 75 Insecticide In Water Soluble Packets solution. Locate galleries by using visual signs (frass or pellets, blistered wood, emergence or clean out holes), the presence of live insects, mechanical sounding techniques, or listening devices (e.g., stethoscopes, acoustic emission detectors). Penetrate the gallery system by drilling holes to receive the injector tip or treatment tool. Distribute drill holes to adequately cover the gallery system. [Do not drill where electrical wiring, plumbing lines, etc. are located.] Apply Premise 75 Insecticide In Water Soluble Packets solutions as a low pressure (about 20 psi) spray or by misting or, where appropriate, by foaming. It is not necessary to treat to the point where runoff is detected from adjacent holes. (Do not apply where electrical shock hazards exist.) Drill holes should be sealed after treatment. Also, wood surfaces can be sprayed or misted with a 0.05 to 0.1% solution or, where appropriate, use a sufficient volume of foam. For inaccessible surfaces, drill and treat the interior of structural voids. Surfaces treated may include exposed wooden surfaces in crawlspaces, basements, or attics, wooden exterior surfaces such as decks, fencing, or siding, structural voids, channels in damaged wood, in spaces between wooden members of a structure, and junctions between wood and foundations. Apply by brushing or as a coarse, low pressure (about 20 psi) spray to the wood surface; apply sufficient volume to cover the surface to the point of wetness, but do not apply to the point of runoff. When spraying overhead in living areas, cover surfaces below the treated area with plastic sheeting or similar material. Do not contact treated surfaces until spray deposits have dried. Retreat as needed to maintain protection.

Localized treatment of carpenter bees. Apply a 0.05 to 0.1% solution as a spray or mist, or sufficient volume of foam, directly into gallery entrance holes. Following treatment, entrance holes may be plugged with small pieces of steel wool or similar material.

RETREATMENT

Retreatment for subterranean termites can only be performed if there is clear evidence of reinfestation or disruption of the treated zone due to construction, excavation, or landscaping and/or evidence of the breakdown of the termiteicide treated zone in the soil. These vulnerable or reinfested areas may be retreated in accordance with application techniques described in this product's labeling. The timing and type of these retreatments will vary, depending on factors such as termite pressure, soil types, soil conditions and other factors which may reduce the effectiveness of the treated zone. Retreatment may be made as either a spot or complete treatment.

When a structure is not known to be reinfested and the treated zone is not disturbed, but where the structure was last treated five or more years ago, retreatment may be performed if, in the judgement of the applicator, it is necessary to ensure adequate protection of the structure. In determining the timing of any retreatment, the applicator should consider efficacy and/or degradation data and/or site-specific conditions and previous experience that indicate a vulnerability of the structure to termite attack.

**Annual retreatment of the structure is prohibited unless there is clear evidence that reinfestation or treated zone disruption has occurred.** When another registered termite control product/system is used as the primary treatment for prevention or control of subterranean termites and is applied to all label-specified areas, Premise 75 Insecticide In Water Soluble Packets may be applied as a spot application in a secondary treatment to critical areas of the structure including plumbing and utility entry sites, bath traps, expansion joints, foundation cracks, the outside foundation wall and areas of known or suspected activity at either a pre-construction or post-construction timing. These secondary treatments must be applied in amounts and concentration in accordance with label directions relevant to the treatment area(s) to receive the secondary treatment.

**For control of ants in houses and other structures,** apply a 0.05 to 0.1% solution as a general surface, spot, crack and crevice or wall void application. Apply to surfaces on buildings, porches, patios and other structures, around doors and windows, eaves and attic vents, utility entry points, soffit areas and other exterior openings (including foundation cracks or drilled holes) where these pests enter the structure or where they crawl or hide. Spray into cracks and crevices. Spray, mist or foam into voids where these ants or their nests are present. Apply the volume of spray mist or foam sufficient to cover the area, but do not allow excessive dripping or run-off to occur from vertical or overhead surfaces.

Treat soil, turf, or non-flowering ground cover adjacent to the structure where ants are trailing or may find food or harborage. To control ants tunneling in soil apply a 0.05 to 0.1% solution as a drench or soil injection at intervals to establish a continuous treated zone. Treat along the edge of walls, driveways or other hard surfaces where ants are tunneling beneath the surface.

**Aerial Nests:** If ant nests are located in tree hollows or non-structural wooden construction (e.g.: posts, fences, decks) treat the interior cavity and/or the nest site by injecting a 0.05 to 0.1% solution as a spray mist, or sufficient volume of foam.

Apply in sufficient water to cover the foliage and soil area being treated. Maximum application is once per month to maintain control.

Do not allow residents or pets into the immediate area during the application or contact with treated areas until spray has dried. Interior applications for ant control are limited to spot, crack and crevice, or wall void application only.

Where severe pest pressures may exist and when rapid knockdown or exclusion at pest entry points is desired, supplemental treatments using Premise 75 Insecticide In Water Soluble Packets with targeted applications of a pyrethroid such as TEMPO® SC ULTRA or SUSPEND® SC to doors and windows, utility entry points, and other places where these pests enter the structure. Read and follow all label directions for use of this companion product.

RESTRICTIONS

**Do not use this product against native or imported fire ants, pharaoh or harvester ants.**

Do not apply solution until location of heat pipes, ducts, water and sewer lines and electrical conduits are known and identified. Caution must be taken to not puncture or inject into these structural elements.

Do not treat within a distance of one foot out from the drip line of edible plants.

Do not contaminate public and private water supplies.

Do not formulate this product into other end-use products.

Do not apply at a lower dosage and/or concentration than specified on this label.

Do not allow this product to contact blooming plants when making perimeter treatments if bees are foraging the treatment area.

Do not apply this product, by any application method, to linden, basswood, or other Tilia species

PRECAUTIONS FOR APPLICATIONS

After treatment, plug and fill all holes drilled in concrete slab areas of the building with a suitable sealant.

Use anti-backflow equipment or an air gap on filling hoses.

Consult State, Federal, or Local authorities for information regarding the approved treatment practices for areas in close proximity to potable water supplies.

STORAGE AND DISPOSAL

Do not contaminate water, food, or feed by storage or disposal.

**Pesticide Storage:** Store in a cool, dry place and in such a manner as to prevent cross contamination with other pesticides, fertilizers, food, and feed. Do not store below freezing (32°F). Exposure to moisture or excessive handling of water soluble packets may cause breakage. Store water soluble packets in original container and out of reach of children, preferably in a locked storage area.

Handle and open container carefully. Do not cut water soluble packets when opening. If container is leaking or material spilled for any reason or cause, carefully sweep material into a pile. Refer to PRECAUTIONARY STATEMENTS on label for hazards associated with the handling of this material. Do not walk through spilled material. Dispose of pesticide as directed below. In spill or leak incidents, keep unauthorized people away. You may contact the Bayer Environmental Science Emergency Response Team for decontamination procedures or any other assistance that may be necessary. The Bayer Environmental Science Emergency Response Telephone No. is 1-800-334-7577.

**Pesticide Disposal:** Wastes resulting from the use of this product may be disposed of on site (in the treatment area) or at an approved waste disposal facility.

**Container Disposal: Non-refillable container.** Do not reuse or refill this container. Offer for recycling, if available. Do not use carton in connection with food, feed or drinking water. The empty foil wrappers may be disposed of in the trash. After removing all PVA packets, the carton may be disposed of in the trash.

IMPORTANT: READ BEFORE USE

Read the entire Directions for Use, Conditions, Disclaimer of Warranties and Limitations of Liability before using this product.

If terms are not acceptable, return the unopened product container at once. By using this product, user or buyer accepts the following Conditions, Disclaimer of Warranties and Limitations of Liability.

**CONDITIONS:** The directions for use of this product are believed to be adequate and must be followed carefully. However, because of manner of use and other factors beyond Bayer CropScience LP's control it is impossible for Bayer CropScience LP to eliminate all risks associated with the use of this product. As a result, crop injury or ineffectiveness is always possible. All such risks shall be assumed by the user or buyer.

**DISCLAIMER OF WARRANTIES:** TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, BAYER CROPSCIENCE LP MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, THAT EXTEND BEYOND THE STATEMENTS MADE ON THIS LABEL. No agent of Bayer CropScience LP is authorized to make any warranties beyond those contained herein or to modify the warranties contained herein. TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, Bayer CropScience LP disclaims any liability whatsoever for special, incidental or consequential damages, resulting from the use or handling of this product.

**LIMITATIONS OF LIABILITY:** TO THE EXTENT CONSISTENT WITH APPLICABLE LAW, THE EXCLUSIVE REMEDY OF THE USER OR BUYER FOR ANY AND ALL LOSSES, INJURIES OR DAMAGES RESULTING FROM THE USE OR HANDLING OF THIS PRODUCT, WHETHER IN CONTRACT, WARRANTY, TORT, NEGLIGENCE, STRICT LIABILITY OR OTHERWISE, SHALL NOT EXCEED THE PURCHASE PRICE PAID, OR AT BAYER CROPSCIENCE LP'S ELECTION, THE REPLACEMENT OF PRODUCT.

Bayer (reg'd), the Bayer Cross (reg'd), Premise®, Temp®, Suspend® and Backed by Bayer™ are trademarks of Bayer.



Produced by:  
**Bayer Environmental Science**  
A Division of Bayer CropScience LP  
2 T.W. Alexander Drive  
Research Triangle Park, NC 27709